Arbor Auger Installation Directions

by Discount Fence Supply, Inc.



1. Identify the "footprint" of the arbor and move temporarily. Ensure that the location of the Aussie Auger Anchors are square



2. Keep the Aussie Augers as level as possible. Design allows for some flexibility.



3. Screw the Aussie Augers into the ground. Apply water before starting in extremely dry conditions.



4. Drop plastic sleeves over installed Aussie Augers.



5. Install protective tip cap horizontally through plastic sleeve into anchor to lock the two together.



6. Slide assembled arbor side panels over plastic sleeves.



7. Install fastening screw through the base molding to secure the arbor to the plastic sleeve.



8. Enjoy!

To Order Call 800-878-7829

Discount Fence Supply, Inc. 10050 Wellman Rd. Streetsboro OH 44241 sales@discountfence.com Www.discountfence.com